











PRODUCT DESCRIPTION

Nerolac Beauty Ceiling Emulsion is formulated with specially modified silicon acrylic binder to give excellent whiteness and spatter resistance. Excellent hiding and smooth finish of this white ceiling paint helps to hide minor surface imperfections. It dries quickly to an eye soothing matt finish.

PERFORMANCE FEATURES & BENEFITS



Excellent Whiteness

Smooth Matt Finish



Excellent Brightness



Anti Fungal





Low Spatter

SURFACE PREPARATION

- Ensure that the plastered surface is clean, dry & free from any loose or poorly-adhering material, dirt, grease, etc.
- Apply a coat of Nerolac Premium Primer according to your need (Solvent/Water Thinnable) and allow it to dry.
- Apply the Nerolac Wall/Cement Putty (wherever required) to level-out the undulations. Sand the surface with emery paper no. 220 and wipe it clean.
- Apply another coat of primer and allow it to dry.
 Sand the surface with emery paper no. 320 and wipe it clean with a cloth before painting.

RECOMMENDED USAGE

Nerolac Beauty Ceiling Emulsion is recommended for Interior Ceiling.

RECOMMENDED SYSTEM FOR APPLICATION - For New Masonry Surfaces

1. Thin 1 L of Nerolac Beauty Ceiling Emulsion with 400-500 ml water. Apply with brush or roller. Allow it to dry for 4 -6 h and then apply 2^{nd} coat

2. Use thinned material within 24 h

PRECAUTIONS

- 1. Refer to the MSDS for "Nerolac Beauty Ceiling Emulsion" for safety measures & precautions.
- 2. Store in well-ambient conditions, ventilated locations & away from any source of ignition and fire.
- 3. Keep it away from children.
- 4. In case of eye/skin contact, wash with plenty of water.
- 5. Inhalation/Injection will cause danger. In either case, get fresh air & consult medical practitioners.
- 6. Do not apply when the ambient temperature might drop to levels below 10°C within 4h of application.
- 7. The new plaster should be allowed to cure for a minimum of 12 weeks.
- 8. Avoid extra-thinning.
- 9. Can be tinted with Nerolac Hi-Power Universal Stainer before thinning. Do not add Nerolac Hi-Power Universal Strainer.
- 10. The container must be tightly closed when not in use. Stir well and strain before use.
- 11. Use safety equipments like rubber or polythene gloves, safety goggles/glasses & face masks.

TECHNICAL DATA FLASH POINT : RECOATING : Minimum 4-6 h @ 27±2°C & RH 60±5% (IS:101(PART-2/SEC-1)/ 1988 & (PART-2/SEC-2)/ 1986 & IS15489/2004): < 50 g/L ++ DRY FILM THICKNESS COVERAGE** In microns 15-20 by 9-12 sq.m/L/2 coats Brush/ (a) 25-30 by Roller GLOSS STABILITY OF THINNED-PAINT: Use within 24 h

POST APPLICATION INSTRUCTIONS

For the best performance, ensure dry dust-cleaning at regular intervals. Allow a drying-time of 3 weeks for proper film-formation before doing any sponge cleaning with a mild soap-solution or mineral turpentine.



DISCLAIMER

The product information and application details given by the company has been provided in good faith and is meant to serve only as a general guideline during usage. The performance claims made are based on the tests carried out under controlled conditions and our past experience with the type of products, therefore actual performance will depend on local factors prevailing at that point of time. Users are advised to carry-out sample tests by taking trials to ensure the suitability of products for their requirement, prior to full-scale usage of our products. The Company is not liable for factors beyond its control such as application during adverse climatic conditions, use of improper application tools/techniques and surface preparation, any structural defects or the inferior quality of materials other than paints. The warranty/guarantee clauses shall accordingly be amended.

^{**}Actual coverage and thickness may vary depending on method, condition of application, Type of Tools, Surface porosity & shades. Use of felt roller may reduce up to 40-50%)